

## INSTALLATION

## BULLET RESISTANT FIXED ALUMINUM WINDOW USAW300



**SINGLE LITE**



**TRANSACTION**

1. Uncrate framing.
2. Insert frame into opening.
3. Shim frame level and plum to fit snug into opening.
4. Drill through pre-drilled holes in perimeter into wall.
5. Insert supplied anchors into walls on all four sides  
Note: shim should be placed at each anchor.
6. Insert inner and outer rubber or tape and setting blocks.
7. Set glass in frame.
8. Install glass stops with supplied 1/4-20 FHMS.
9. Caulk as needed around framing.
10. Reference approved shop drawings for detailed installation.

