


INSTALLATION

BULLET RESISTANT FIXED ALUMINUM WINDOW USAW300



SINGLE LITE



TRANSACTION

1. Uncrate framing.
2. Insert frame into opening.
3. Shim frame level and plum to fit snug into opening.
4. Drill through pre-drilled holes in perimeter into wall.
5. Insert supplied anchors into walls on all four sides
Note: shim should be placed at each anchor.
6. Insert inner and outer rubber or tape and setting blocks.
7. Set glass in frame.
8. Install glass stops with supplied 1/4-20 FHMS.
9. Caulk as needed around framing.
10. Reference approved shop drawings for detailed installation.

